



The ultimate {Golf Launchpad} cheat-sheet {for Pros}

{Install}

- ✓ Download and install the latest **LPDR** from www.electricspin.com/software
- ✓ Install EA Sports' Tiger Woods 2008 from the DVD supplied, and ensure that the installation *completes fully and without errors*. Your computer must be 100% compatible with the system requirements for Tiger '08. If applicable, download and install any updates to Tiger '08.

{Setup and play}

- ✓ Disable all virus checkers, disconnect Launchpad and start the computer from a fresh reboot.
- ✓ Start LPDR and, when prompted, plug in Golf Launchpad. Wait until the main window appears, then enable the **Game>Tiger Woods 08** menu item (it must be checked). LPDR must continue running in the background while playing Tiger.
- ✓ For most accurate play set Shot Difficulty to Hard in LPDR
File>Preferences>Advanced
- ✓ Start TigerWoods 2008 and run with following settings:
 - Golfer: **Tiger Woods**
 - Difficulty Level: **Advanced** or higher
 - Commentary Level: **High**
 - Tournament atmosphere: **On**
- ✓ Learn to activate Launchpad in the **DRIVE, CHIP/PITCH** and **PUTT** modes and when to use each. Optional: learn to play the entire game with a mid/short iron and putter for constrained-space use or when you just can't be bothered!
- ✓ Ensure the best sides of the Grip Pads are facing down for minimal movement of Launchpad (for best accuracy).
- ✓ Know the Remote Caddy functions and how they work.
- ✓ Take the time to gain proficiency with the myriad features within Launchpad, LPDR and Tiger Woods. You'll be surprised how much there is for all skill levels to benefit from and enjoy. There's always help available if you require it: www.electricspin.com/support



Rev 1.1C (9-09)